

# SWITCHES

## SW12958

FUSED PUSH-PULL HEADLIGHT SWITCH (ON-OFF)

INTERRUPTOR CON FUSIBLE DEL PULSADOR-JALADOR PARA FAROS (ENCENDIDO-APAGADO)

MAX. AMPERAGE: 15 A | CORRIENTE MÁXIMA: 15 A

Drill 7/16" hole

Haga un agujero de 1.11cm

· Universal headlight switch for older vehicles

**CAUTION:**

All circuits should include an in-line fuse for safety.  
Disconnect power source before any electrical repair.

**INSTALLATION INSTRUCTIONS:**

1. Disconnect battery.
2. Attach the wires as shown in the diagram.
3. Reconnect the battery.
4. Test the switch.

**NOTE:** This gives you the chance to test the unit prior to final installation.

5. Complete final installation of the switch in its desired location.

· Interruptor de faros universal para los vehiculos más viejos

**ADVERTENCIA:**

Todos los circuitos deben incluir un fusible en línea por razones de seguridad. Desconecte la fuente de energía antes de realizar toda reparación eléctrica.

**INSTRUCCIONES DE INSTALACIÓN:**

1. Desconecte la batería.
2. Conecte los cables como se muestra en el diagrama que aparece.
3. Vuelva a conectar la batería.
4. Pruebe el interruptor.

**NOTA:** Esto le da la posibilidad de probar la unidad antes de realizar la instalación final.

5. Complete la instalación final del interruptor en la ubicación deseada.

