



TERMINALS

BUTT CONNECTORS

ITEM #	AWG	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
T13722 / TBP-R	22-18	PVC	21	120	Red
T12833 / TBP-R	22-18	PVC	100	120	Red
TBP-R-B	22-16	PVC	1,000	10	Red
T13723 / TBP-B	16-14	PVC	21	120	Blue
T12835 / TBP-B	16-14	PVC	100	120	Blue
TBP-B-B	16-14	PVC	1,000	10	Blue
T13732 / TBP-Y	12-10	PVC	13	120	Yellow
T12837 / TBP-Y	12-10	PVC	50	120	Yellow
TBP-Y-B	12-10	PVC	500	10	Yellow
T13733 / TBP-R	22-16	PVC	7	120	Red
T13733 / TBP-B	16-14		5		Blue
T13733 / TBP-Y	12-10		4		Yellow
TBN-R-B	22-16	Nylon	1,000	10	Red
TBN-B-B	16-14	Nylon	1,000	10	Blue
TBN-Y-B	12-10	Nylon	500	10	Yellow

Installation Instructions

- 1) Strip wire insulation 1/4"
 - 2) Insert stripped wire into terminal
 - 3) Crimp tightly using crimping tool
- Stranded copper wire only

UL Listed

PVC Insulation

600V
75°C

Nylon Insulation

600V
105°C

**premium.
industrial.
products.**