



# TERMINALS

## FLAG DISCONNECTS

ITEM #	AWG	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
TFLDN-R-B	22-18	Nylon	1,000	10	Red
TFLDN-B-B	16-14	Nylon	1,000	10	Blue

### Installation Instructions

- 1) Strip wire insulation 1/4"
  - 2) Insert stripped wire into terminal
  - 3) Crimp tightly using crimping tool
- Stranded copper wire only

### Nylon Insulation

600V  
105°C

### UL Listed

**premium.  
industrial.  
products.**