



TERMINALS

QUICK SPLICE CONNECTORS

ITEM #	AWG	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
T12862 / TQS-R	22-16	PVC	5	10	Red
TQS-R-B	22-16	PVC	1,000	10	Red
T13728 / TQS-B	18-14	PVC	7	120	Blue
T13731 / TQS-B	18-14	PVC	25	60	Blue
TQS-B-B	16-14	PVC	1,000	10	Blue
T12863 / TQS-Y	12-10	PVC	4	10	Yellow
TQS-Y-B	12-10	PVC	1,000	5	Yellow
T13745 / TQS-R	22-16	PVC	6	60	Red
TQS-B	18-14		12		Blue
TQS-Y	12-10		3		Yellow

Installation Instructions

- 1) Strip wire insulation 1/4"
 - 2) Insert stripped wire into terminal
 - 3) Crimp tightly using crimping tool
- Stranded copper wire only

PVC Insulation

600V
75°C

UL Listed

**premium.
industrial.
products.**