



TERMINALS

SPADE TERMINALS

ITEM #	AWG	SIZE SPEC	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
TSP-R4-B	22-16	No. 4 Stud	PVC	1,000	10	Red
TSP-R6-B	22-16	No. 6 Stud	PVC	1,000	10	Red
TSP-R8-B	22-16	No. 8 Stud	PVC	1,000	10	Red
TSP-R10-B	22-16	No. 10 Stud	PVC	1,000	10	Red
TSP-R25-B	22-16	1/4" Stud	PVC	1,000	10	Red
TSP-B4-B	16-14	No. 4 Stud	PVC	1,000	10	Blue
TSP-B6-B	16-14	No. 6 Stud	PVC	1,000	10	Blue
T12860 / TSP-B8	16-14	No. 8 Stud	PVC	10	120	Blue
TSP-B8-B	16-14	No. 8 Stud	PVC	1,000	10	Blue
TSP-B10-B	16-14	No. 10 Stud	PVC	1,000	10	Blue
TSP-B25-B	16-14	1/4" Stud	PVC	1,000	10	Blue
TSP-B516-B	16-14	5/16" Stud	PVC	1,000	10	Blue
TSP-Y6-B	12-10	No. 6 Stud	PVC	500	10	Yellow
TSP-Y8-B	12-10	No. 8 Stud	PVC	500	10	Yellow
T12858 / TSP-Y10	12-10	No. 10 Stud	PVC	10	120	Yellow
TSP-Y10-B	12-10	No. 10 Stud	PVC	500	10	Yellow
TSP-Y25-B	12-10	1/4" Stud	PVC	500	10	Yellow
TSP-R8	22-16	No. 8 Stud	PVC	8	120	Red
T12859 / TSP-B8	16-14	No. 8 Stud		7		Blue
TSP-Y8	12-10	No. 8 Stud		5		Yellow

Installation Instructions

- 1) Strip wire insulation 1/4"
 - 2) Insert stripped wire into terminal
 - 3) Crimp tightly using crimping tool
- Stranded copper wire only

PVC Insulation

600V
75°C

UL Listed

**premium.
industrial.
products.**