



# TERMINALS

## WEATHERPROOF HEAT SHRINK BUTT CONNECTORS

ITEM #	AWG	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
T13727 / THBN-R	22-18	Weatherproof	10	120	Red
T13724 / THBN-B	16-14	Weatherproof	10	120	Blue
T13737 / THBN-Y	12-10	Weatherproof	7	120	Yellow

### Installation Instructions

- 1) Strip wire insulation 1/4"
  - 2) Insert stripped wire into terminal
  - 3) Crimp tightly using crimping tool
- Stranded copper wire only

### Insulation

600V  
105°C

### UL Listed

**premium.  
industrial.  
products.**