



# TERMINALS

## WEATHERPROOF QUICK SPLICE CONNECTORS

ITEM #	AWG	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
T13742	18-14	Weatherproof	4	120	Blue

### Installation Instructions

- 1) Strip wire insulation 1/4"
  - 2) Insert stripped wire into terminal
  - 3) Crimp tightly using crimping tool
- Stranded copper wire only

### Insulation

600V  
105°C

### UL Listed