

# SWITCHES

## SW12920

UNIVERSAL STARTER SWITCH WITH KEYS | INTERRUPTOR DEL ARRANCADOR UNIVERSAL CON LLAVES  
 MAX. AMPERAGE: 30 A | CORRIENTE MÁXIMA: 30 A

3/4" diameter mounting stem  
 Vástago de montaje de 1.9 cm de diámetro

**CAUTION:**

All circuits should include an in-line fuse for safety. Disconnect power source before any electrical repair.

**INSTALLATION INSTRUCTIONS:**

1. Disconnect battery.
2. Drill 3/4" hole in mounting location.
3. Wire circuit as illustrated.
4. Install switch in hole and tighten nut. **CAUTION:** Do not overtighten nut - maximum torque is 12 inch pounds.
5. Reconnect battery.

**ADVERTENCIA:**

Todos los circuitos deben incluir un fusible en línea por razones de seguridad. Desconecte la fuente de energía antes de realizar toda reparación eléctrica.

**INSTRUCCIONES DE INSTALACIÓN:**

1. Desconecte la batería.
2. Perfore un orificio de 1.9 cm en la ubicación de montaje.
3. Realice el cableado como se ilustra.
4. Instale el interruptor en el orificio y apriete la tuerca. **ADVERTENCIA:** No ajuste la tuerca de más; el torque máximo es de 12 libras por pulgada.
5. Vuelva a conectar la batería.

