



TERMINALS

COPPER RING LUGS

ITEM #	SIZE SPEC	MATERIAL	QTY/PACK	PACKS/CASE
T11738 / CRL-138	3/8	Copper	1	120
T13726 / CRL-238	3/8	Copper	2	120
T13768 / CRL-625	1/4	Copper	6	120
T13767 / CRL-638	3/8	Copper	6	120

Installation Instructions

- 1) Strip wire insulation 1/4"
 - 2) Insert stripped wire into terminal
 - 3) Crip tightly using crimping tool
- Stranded copper wire only

UL Listed